

## **Quick Installation Guide**

AC 1750 Wireless Dual Band Gigabit ADSL2+ Modem Router

Please select the appropriate setup wizard.


## **CD Setup Wizard**

For Windows users only

## **Web-based Quick Setup Wizard**


For users unable to run the Resource CD

MODEL NO. Archer D7



## **CD Setup Wizard** (For Windows users only)

Insert the TP-LINK Resource CD into the CD-ROM drive.




Click Start Setup.



Follow the pop-up flash video to connect your devices, then click to continue.




Please check the LEDs (especially the ADSL LED). Then click **NEXT** and follow the step-by-step instructions until you complete the configuration.




For the advanced configurations, please refer to the User Guide on the Resource CD provided.

## Web-based Quick Setup Wizard (For users unable to run the Resource CD)

Connect your devices step by step following the figure.



Press the power **ON/OFF** button of your modem router and make sure the LEDs (especially the ADSL LED) display as shown below.



Set your computer to **Obtain an IP address / DNS server** address automatically. For details, please refer to T1 in Troubleshooting.

Open your browser and type in http://tplinkmodem.net in the address field, then press Enter. Use the default user name admin and password admin to log into the Web-based management page.



Click **Quick Setup** in the main menu and then click **Next** to start the configuration.

Status	Quick Setup - Start		
Quick Setup	Quick Setup - Start		
Operation Mode			
Network	This guide will help you set basic parameters for Internet connection. Please click NEXT to continue.		
IPTV			
DHCP Server	For function or parameter details, please select the corresponding menu options on the left.		
Dual Band Selection			
Wireless 2.4GHz	Next		



## Web-based Quick Setup Wizard (For users unable to run the Resource CD)

Username:

Password:

Select your **Region** and **Time Zone** from the drop-down list, then click Next.



Select Yes and then click Next to detect the connection




If the connection type can not be detected, please select **No...** to configure it manually.

Here we use **PPPoE** as an example. Enter the **Username** and **Password** provided by your ISP and then click Next.

Quick Setup - PPPoE		
Auto-detection has succeeded!		
DSL PVC:	8/35	
Encapsulation Mode:	LLC	
Connection Type:	PPPoE	
Please enter the Username and Password. If the Username/Password are unknown, please contact your ISP.		
Username:		
Password:		
Confirm password:		
	Back Next	
Record this information here	2:	

You can rename your 2.4GHz wireless network and create your own password in this page. The default wireless name is TP-LINK\_2.4GHz\_XXXXXX; and the




default wireless password, the same as the PIN code, is

You can rename your 5GHz wireless network and create your own password in this page. The default wireless name is TP-LINK\_5GHz\_XXXXXX; and the default wireless password, the same as the PIN code, is printed on the bottom label. Click Next to continue.



Record your wireless information here:	
2.4GHz SSID:	
2.4GHz Security Password:	
5GHz SSID:	
5GHz Security Password:	

Please confirm all the parameters. Click **Back** to modify them or click **Save** to save your settings.



Quick Setup has completed. Click Finish to make your settings take effect.

The basic settings for your modem router are completed. Please open the web browser and try to log on to http://www.tp-link.com to test your Internet connection



For the advanced configurations, please refer to the User Guide at http://www.tp-link.com

## **Troubleshooting**

## T1. How can I set my computer to Obtain an IP address / DNS server address automatically?

## For Mac OS X

- 1) Click the **Apple** icon on the upper left corner of the screen.
- 2) Go to "System Preferences -> Network".
- Select Airport on the left menu bar, and then click Advanced for wireless configuration; or select **Ethernet** for wired configuration.
- In the Configure IPv4 box under TCP/IP, select Using DHCP.
- Click **Apply** to save the settings.

## For Windows 7

- 1) Click "Start -> Control Panel -> Network and Internet -> View network status -> Change adapter settings".
- Right-click Wireless Network Connection (or Local Area Connection), and then click Properties.
- Select Internet Protocol Version 4 (TCP/IPv4), and then click Properties.
- Select Obtain an IP address automatically and Obtain DNS server address automatically. Then click OK.

## **For Windows XP**

- Click "Start -> Control Panel -> Network and Internet Connections -> Network Connections".
- Right-click Wireless Network Connection (or Local Area Connection), and then click **Properties**.
- Select Internet Protocol (TCP/IP), and then click Properties.
- Select Obtain an IP address automatically and Obtain DNS server address automatically. Then click OK.

## For Windows 8

Move your mouse to the lower right corner and click the **Search** icon in the Popups.

- 2) Go to Apps, type Control Panel in the search box and press Enter.
- 3) Go to "Control Panel -> View network status and tasks > Change adapter settings".
- 4) Right-click **Ethernet**, select **Properties**. Then double-click **Internet** Protocol Version 4 (TCP/IPv4).
- Select Obtain an IP address automatically and Obtain DNS server address automatically. Then click OK.

### T2. What can I do if I cannot access the Internet?


- 1) Check your cables and make sure they are all plugged in correctly, including the telephone line, Ethernet cables and power adapter.
- 2) Check to see if you can log on to the Web-based management page of the modem router. The default address of the Web-based management page is http://tplinkmodem.net. If you can, try the following steps. (If you can not, please refer to **T1** to configure TCP/IP Properties and then try to access the Internet again.)
- Consult your ISP and make sure all the VPI/VCI, Connection Type, account username and password are correct. If they are not, please replace them with the correct settings and try again.
- If you still cannot access the Internet, please restore your modem router to its factory default settings and reconfigure your modem router following the instructions in this QIG.
- 5) Please contact our Technical Support if the problem still exists.

## T3. How can I restore my modem router's configuration to its factory default settings?

Once the modem router is reset, the current settings will be lost and you will need to reconfigure the modem router. We strongly suggest you back up

the current settings before resetting the modem router. For more Backup information, please refer to 4.23.6 Backup & Restore on User Guide.

With the modem router powered on, use a pin to press and hold the RESET button on the rear panel for 8 to 10 seconds before releasing it.



## T4. What can I do if I forget my password?

- 1) For default wireless password: Please refer to the "Wireless Password/PIN" labeled on the bottom of the modem router.
- 2) For the web management page password: Reset the modem router first and then use the default user name and password: admin/admin.

## T5. How can I configure the USB features?

Please refer to our Application Guides. They can be found on the resource CD, or on the web.

- 1) CD Access: Open the "Application Guide" folder on the Resource CD. The guides can be found inside this folder.
- Web Access: http://www.tp-link.com/app/usb



For more details about Troubleshooting and Technical Support contact information, please log on to our Technical Support website: http://www.tp-link.com/en/support





- To download the latest Firmware, Driver, Utility and User Guide, go to
- http://www.tp-link.com/en/support/download

  For all other technical support, please contact us by using the following details:

Tel: +86 755 2650 4400 ding on rate of different

USA / Canada Toll Free: +1.866.225.8139

Service time: 24hrs, 7days a week UK Tel: +44 (0) 845 147 0017

Tel: +44 (0) 845 147 0017 Fee: Landline: 1p-10.5p/min, depending on the time of day. Mobile: 15p-40p/min, depending on your mobile network. E-mail: support.uk@tp-link.com Service time: 24hrs, 7days a week

E-mail: suporte.br@tp-link.com Service time: Monday to Friday, 09:00 to 20:00; Saturday, 09:00 to 15:00

Fee: Depending on rate of different carriers. E-mail: support.it@tp-link.com Service time: Monday to Friday, 09:00 to 13:00; 14:00 to 18:00 Indonesia

## Germany / Austria

Tel :+49 1805 875 465 (German Service) +49 1805 TPLINK +43 820 820 360

# +43 820 820 360 Fee: Landline from Germany: 0.14EUR/min. Landline from Austria: 0.20EUR/min. E-mail: support.de@tp-link.com Service Time: Monday to Friday, 09:00 to 12:30 and 13:30 to 18:00. GMT+1 or GMT+2 (DST in Germany) \* Except bank holidays in Hesse

## **Technical Support**

carriers, IDD.
E-mail: support@tp-link.com
Service time: 24hrs, 7 days a week

E-mail: support.usa@tp-link.com (USA) support.ca@tp-link.com (Canada)

Tel: 0850 7244 488 (Turkish Service)
Fee: Depending on rate of different carriers.
E-mail: support.tr@tp-link.com
Service time: 09:00 to 21:00, 7days a week

## <u>Brazil</u>

Tel: +39 023 051 9020

Indonesia
Tel: (+62) 021 6386 1936
Fee: Depending on rate of different carriers.
E-mail: support.id@tp-link.com
Service time: Sunday to Friday, 09:00 to12:00, 13:00 to 18:00 \*Except public holidays

## AU 1300 87 5465 (Depending on 1300 policy.) E-mail: support.au@tp-link.com (Australia) support.nz@tp-link.com (New Zealand) Service time: 24hrs, 7 days a week

## Singapore

Tel: +65 6284 0493 Fee: Depending on rate of different carriers.

Tel: 0800 505 508 Fee: Free for Landline; Mobile: Depending on rate of different carriers E-mail: support.ua@tp-link.com Service time: Monday to Friday, 10:00 to 22:00

Toll Free: 1300 88 875 465 E-mail: support.my@tp-link.com Service time: 24hrs, 7days a week Tel: +48 (0) 801 080 618 +48 223 606 363 (if calls from mobile phone)

## Fee: Depending on rate of different carriers. E-mail: support.pl@tp-link.com Service time: Monday to Friday, 09:00 to 17:00. GMT+1 or GMT+2 (DST)

Tel: +41 (0)848 800 998 (German Service) Fee: 4-8 Rp/min, depending on rate of different

## E-mail: support.ch@tp-link.com

Service time: Monday to Friday, 09:00 to 12:30 and 13:30 to 18:00. GMT+ 1 or GMT+ 2 (DST) France

## Tel: 0820 800 860 (French service) Fee: 0.118 EUR/min from France Email: support.fr@tp-link.com Service time: Monday to Friday, 09:00 to 18:00 \*Except French Bank holidays

Russian Federation
Tel: 8 (499) 754 5560(Moscow NO.)
8 (800) 250 5560 (Toll-free within RF) E-mail: support.ru@tp-link.com Service time: From 09:00 to 21:00 (Moscow time)

TP-LINK TECHNOLOGIES CO., LTD. www.tp-link.com